

Application of your Rhinestone Transfers...

Once you receive your transfers to properly apply your transfer you will need either a heat press or iron. Using a heat press is the easiest method as proper temperature and time can be set.

The temperature for applying transfers should be around 320 degrees. The cotton setting on a hand iron should be appropriate. Typical heat application time is 10 seconds.

Choose the right material to use to apply your Rhinestone Transfer. Many materials will hold a transfer but you may want to test your material for both the ability to hold up to the heat and for its ability to hold the actual Rhinestones.

After the proper material is chosen and tested...

Lay out your material / clothing on a flat surface able to withstand the heat.

Take your transfer and remove the backing material (white). This will leave the clear transfer tape and rhinestones. Apply the sticky side down onto your material. Make sure that the transfer is located where you want the final design to be.

Apply heat to activate the glue on the rhinestones.

Let the transfer cool so that it is not too hot to touch.

Remove the clear transfer tape.

Congrats Your Done!

Remember to get the longest life out of your newly created Rhinestone design wash inside out on a cold setting and dry on low heat.